



## ARB Awning Instructions

1. Undo the zip on the PVC bag, and release the buckles holding the awning in place.
2. Release the awning rafter arms from the velcro dots holding them onto the main aluminium extrusion. Swing both rafter arms slightly More than 90° away from the vehicle. See 1
3. Allow the awning to unroll in your hands to its full length. See 2
4. Release the legs of the awning from inside the front beam. Slide the inner leg tube to the desired height and engage the twist lock of The leg by turning the bottom half of the leg to lock the leg in place. See 3
5. With one hand holding the front beam, extend the rafter arm, and place the arm pin into the corresponding hole in the front beam. Twist the arm to engage the twist lock. See 4 and 5
6. Secure the fabric to the rafter arms using the velcro tabs.
7. Peg the legs to the ground using the rope loops in the feet, and guy rope to secure in case of winds. See 6
8. Pack up is simply the reverse of the above procedure.
9. Note - In the event of rain ensure that the awning is set to an appropriate angle to allow rainwater to run off and not accumulate on top of the awning.

### **WARNING**

**High winds can tear the awning. Please don't use awning in high winds!**

**Make sure you don't lose the poles. It will be your responsibility to replace them (and they are expensive).**

**Don't drive with the awning out.**

Have fun and drink a cold one under the shade of the awning for us.  
Cheers - Lost Campers Crew

