



USE



TB 45A-55A



TB 31-41-51

- Plug in the DC or AC power. Press the button 'ON/OFF' to run the refrigerator. The LED display on the control panel would be lighted and the interior temperature would be displayed.
- Press the button Δ and ∇ to adjust the temperature. Press the button Δ to increase while the button ∇ to decrease the temperature. When press the above two buttons at the same time, it would switch the display between $^{\circ}\text{C}$ and $^{\circ}\text{F}$.
- Press the ECO key to enter the "ECONOMY" operating mode: the ECO light turns on and the compressor runs at minimum speed by keeping a fresh temperature inside the refrigerator. By pressing the ECO key again, the light turns off and the refrigerator enters in MAX mode (mode (maximum number of compressor turns). MAX light will be switched on until having achieved the temperature set.

USEFUL ADVICE

1) Use the product in MAX mode in these cases:

- use of the product as refrigerator and/or freezer with high ambient temperature;
- when the suitable temperature need to be achieved in few time.

2) Use the product in ECO mode in these cases:

- use of the product as refrigerator and, in particular, with low ambient temperature;
- when the vehicle is parked for long time (with engine switched off)